



Insulated wire link must connect "regulator in" to "regulator out" as shown.

Bottom view (side with ATmega328P)

## Connection diagram (external regulator/unregulated)